
Maintenance Colours, AS2700-2011

The colours listed below are currently included within Development Control Plan 2014 Chapter C1 – Non-indigenous Heritage, C1.3 Maintenance colours and have been transposed for reference during the consultation period.


Notes regarding use of the Table:

- 1. Heritage colours are the paint colours that were used commonly on traditional buildings prior to the 1950s when there was a substantial shift in taste and manufacturing that created wider availability and use of paint colours including strong new colours.
- 2. The colours listed in Table C1.1 are Australian Standard Colours selected from the AS2700—2011 Colour Standards for General Purposes. They include most of the more common traditional paint colours.
- 3. Group A colours are the wall body colours. They are predominantly natural earth tones (mineral or stone colours) that would be found in nature. On a typical weatherboard cottage these colours would be used on the weatherboards or body of the building.
- 4. Group B colours are lighter tones of the Group A colours. Group C colours are darker tones of the same. They are used on doors, windows and trim to contrast with the wall body colours. In a typical colour scheme, the walls would be painted in a mid-tone, the window and door frames would be lighter and the door and sashes darker. Or the frames might be darker and the window sashes lighter.
- 5. Group D colours are special use colours for elements such as cast-iron railings, columns and friezes, which were most commonly painted in dark tones. They might be used also on special elements such as front doors.
- 6. Group E colours have specific uses. The light green tones are commonly used on the undersides of awnings and verandahs and sometimes on eaves soffits, being cool anti-glare colours. The cream and dark brown colours are used together on the AC sheet and timber battens of gables on buildings of the 1930s to 1950s.
- 7. Group F colours are high visibility and high contrast colours used for signage. They should not be used on a heritage building except as signage.



Page 1 of 3 #E2023/14189







Page 2 of 3 #E2023/14189









Reference: AS2700 Colour Chart | Dulux Protective Coatings

Page 3 of 3 #E2023/14189